# THE NEW GOLD STANDARD.

R5. The 5-axis milling machine for non-stop wet and dry production.





# YOUR TICKET TO THE DENTAL HALL OF FAME.

### Simply process everything, 24 hours a day.

With the R5 you play in a new league of productivity: non-stop milling and grinding with maximum material freedom. You save valuable time by one-hand loading the changer with up to ten disks; this **DirectDisc**Technology is patent-pending.

And there is more! Switch quickly and effortlessly between wet and dry machining with the **DirectClean**Technology. An ingenious package of ionizer, self-cleaning and dryer enables you to produce first-class restorations around the clock.



### Save time through automation.

Up to ten discs or 60 blocks or abutments can be processed without interruption. The easy-to-load, removable changer for 16 tools enables a production without user intervention.

### Reliability meets accuracy.


The R5 offers German engineering at its best — with an impressive 150 kilograms of weight on a minimal footprint. The result: a machine rigidity that meets the highest demands. A repetition accuracy of the linear axes of  $\pm 0.003$  mm guarantees maximum precision in UltraHD and lowest-vibration operation.



The R5 swivels the spindle (B axis) by up to ±35°. This means that the workpiece holder only needs one moving axis (A axis) and the entire system gains stability.

For wet machining, the R5 grinds and mills with clear water. For all materials, except titanium, without any additives — better for your materials and without annoying disposal.

Moreover, the **DirectClean**-Technology enables a swift switch to dry milling.



# A FLAGSHIP THAT IS MOST COMFORTABLE TO NAVIGATE.



### **Highest Precision**

- Restorations in ultra HD
- High-precision spindle with 800 watts of power and 80,000 RPM
- · 3 microns repetition accuracy



### **Absolute Independence**

- Sheer unlimited material accessibility in 98 mm disc format, 38 block materials, and 800+ titanium and CoCr prefab abutment blanks
- Covers the broadest range of indications, due to ±35° rotation angle in the 5<sup>th</sup> axis, and up to 40 mm discs



### **Powerful and Robust**

- Mills and grinds the toughest materials on the market including all Ti and CoCr
- Proven industrial quality



### **Unmatched Reliability**

- 100% engineered and manufactured in Germany
- Comprehensive sensor technology to monitor all vital system functions
- Webcam in working chamber for remote monitoring



### **Highly Economical**

- One of the fastest machines on the market
- Revolutionary material loading with **DirectDisc**Technology (patent pending)
- Automatic changer holds up to 10 discs, 60 blocks, or 60 prefab abutment blanks
- DirectCleanTechnology enables wet and dry on the fly: ionizer, self-cleaning and built-in dryer (patent pending)
- Drilling of screw access channels saves costs for meso blocks

# MATERIAL, MANUFACTURER, INDICATION. ENJOY THE FREEDOM OF CHOICE.

# Anything goes: discs, blocks, and abutments composites plastics/wax glass ceramics zirconia titanium CoCr Maximum freedom of indication crown/bridge inlay/onlay abutment telescopic crown model plate

model tooth

secondary crown

implant bar

occlusally screw-

retained bridge



model cast

drilling template

"Talk about precision and speed! This milling machine is unparalleled."

**Dr. Miguel Stanley** 

occlusal splint

Founder and CEO of White Clinic, Lisbon, Portugal

# A MATTER OF FACTS. TECHNICAL DATA.













CENTEDAL		
GENERAL		

Fields of application Wet and dry machining Materials Plastics, wax, zirconia, composites, CoCr, model plaster, glass ceramics, titanium

Crowns, bridges, fully anatomical crowns and bridges, inlays, onlays, abutments, telescopic crowns, models, model casting, Indications

bite splints, implant bars, veneers, drilling templates, dentures, etc

BASIC SYSTEM

Construction Machine bed of massive aluminum cast

Number of axes

Precise ball screw spindles for the 3 linear axes · motor resolution <1 µm · ground steel precision guide rails Drives

Repetition accuracy linear axes ±0.003 mm

Complete encapsulation of the working chamber with automatically lockable front cover - automatic cover for blank changer Housing

Working chamber illumination/camera system 4 RGB LED with status indication, 3 of them in the working chamber and 1 in the blank changer - camera in working chamber

Dimensions (W/D/H) Approx. 580 × 600 × 700 mm (required seating area: approx. 490 × 294 mm · housing fully open: approx. 580 × 720 × 880 mm)

Weight Approx. 150 kg

**ROTARY AXES** 

A axis: Harmonic Drive® free from backlash for highest true running accuracy · rotation range: 360° infinitely Features

B axis: precise ball screw spindle · rotation range: ±35°

Fixing device Round universal blanks with a thickness of 10 to 40 mm and 98.5 mm diameter with step · for block machining: 6-fold block

holder for blocks up to  $40 \times 20 \times 20$  mm

Exchange of workpieces Automatic changer for up to 10 discs

CONTROLLER

Features Simultaneous interpolation of 5 axes · depending on the country, a separate control of 3 and 2 axes each might be necessary

due to export regulations

SPINDLE Features

Rotational speed range up to 80,000 RPM  $\cdot$  Peak power ( $P_{max}$ ): 800 Watt  $\cdot$  nominal power under periodic operation (S6): 600 Watt  $\cdot$  nominal power under continuous operation (S1): 440 Watt  $\cdot$  4-fold bearing  $\cdot$  hybrid ceramic ball bearing  $\cdot$  concentricity deviation at the inner taper of the precision shaft < 3 µm · sealing air prevents entering of debris or moisture in the

Collet chuck Pneumatic stainless steel collet chuck with ceramic coating for tools with 3 mm shank diameter and max. 40 mm total length

**TOOL CHANGE** 

Features Automatic tool changer for 16 tools with length detection and tool breakage monitoring via measuring key · exchangeable

tool changer inserts

WET GRINDING

8 liquid nozzles at the spindle  $\cdot$  integrated reservoir (3 liters) for cooling liquid  $\cdot$  protection of mechanics, electronics and

spindle by flexible rubber gaiter · no grinding additives necessary except for milling titanium

SUCTION

Features

Features Opening at the housing side for air extraction · underpressure sensor for monitoring the air extraction · 24 Volt output for

switching suction units

OTHER

Additional equipment For abutment production: holders for various systems

North America model: certification according to ANSI/UL 61010-1 for USA and Canada Special features

CONNECTION REQUIREMENTS

6 bar · 100 l/min − 8 bar · 110 l/min · air purity see ISO 8573-1:2010 Compressed air supply

Power supply 100 - 240 Volt · 50/60 Hz, max. 750 Watt

Network Ethernet RJ45 port for communicating with the computer

**ENVIRONMENTAL CONDITIONS** 

Temperature and relative humidity Between 10 °C and 35 °C · relative humidity: max. 80%, non-condensing

SCOPE OF DELIVERY

Inclusive

Spindle service set  $\cdot$  power cable  $\cdot$  Ethernet network cable (type: straight)  $\cdot$  pneumatic hose  $\cdot$  torque wrench (1.8 Nm – for mounting blocks) · hex key (2.5 mm) · crevice nozzle (for cleaning the working chamber) · interdental brush (for cleaning the nozzle plate) - cleaning brush - drill (2.8 mm) for tool positions - tool magazine insert - calibration set (1 micrometer, blanks for manufacturing test and calibration specimen)  $\cdot$  measuring pin  $\cdot$  block holder  $\cdot$  carrying aid for transporting the machine printed operating instructions









